MAINTENANCE ITEM	MONTH	3	6	12	18	24	30	36	42	48	54	60	66	72	78	84	90	96	102	108	114	120
	KMx1,000	5	10	20	30	40	50	60	70	80	90	100	110	120	130	140	150	160	170	180	190	200
Engine Oil CK4 10W40 @ 6L	Normal Usage	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R
	Severe Usage	Replace every 5,000 km																				
Engine Oil Filter	Normal Usage	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R
	Severe Usage	Replace every 5,000 km																				
Diesel Filter Element	Normal Usage		I	R	I	R	I	R	I	R	I	R	I	R	I	R	I	R	I	R	I	R
	Severe Usage	Replace every 5,000 km																				
Radiator Coolant @ 12L					R			R			R			R			R			R		R
Air Filter	Normal Usage			R		R		R		R		R		R		R		R		R		R
	Severe Usage	Replace every 10,000 km																				
MT Transmission Oil @	Normal Usage			R		R		R		R		R		R		R		R		R		R
	Severe Usage	Replace every 6 months																				
Rear Axle Oil @ 4L	Normal Usage					YES				YES				YES				YES				YES
	Severe Usage																					
Power Steering Fluid @ 3L						R				R				R				R				R
Suspension & Ball Joint Lubrication			L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L
Transmission Release Fork Shaft					L			L			L			L			L			L		
Brake and clutch fluid						R				R				R				R				R
Engine Timing belt set		Replace every 3 years or 100,000 km																				
Engine drive belt				I		I		I		I		I		I		I		I		I		I
Electrical and Equipment & lighting System		I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
Refrigerant Gas & Compressor Oil				I		R		I		R		I		R		I		R		I		R
Battery Electrolyte Specific Weight or Voltage		I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I